

伯东企业（上海）有限公司
您理想的真空合作伙伴！

叶南晶 139-1883-7267



伯东企业（上海）有限公司
HAKUTO ENTERPRISES (SHANGHAI) LTD.

TEL: (86) 21-5046 3511 分机101 www.hakuto-vacuum.cn

上海伯东 -- 您理想的真空合作伙伴！

伯东公司成立于 1953 年，外企上市企业，全球范围内有一千七百名员工，集团年营业额约为 100亿人民币。

伯东公司在国内主要城市：上海，北京，苏州，广州，深圳，成都及厦门设有营业据点。

上海伯东真空产品事业部已累计为超过 10,000 家企业提供真空服务

我们致力于追求高品质的服务，为您提供一流的服务及一流产品：

品质保障：国际知名品牌指定授权代理商，所有产品及部件保证 100% 原厂原装进口

现货交期快：部分产品有现货，下单立即发货（现货数量有限，实际情况请联系销售工程师）

卓越维修能力：伯东工程师拥有10年以上维修经验，且受国外专业培训，拥有完全的拆解，维修，校正能力。

完美服务质量：原装进口检测设备全方位寻找问题症结及全方面的性能测试，确保完美的服务质量



伯东企业（上海）有限公司 销售及售后服务中心

上海浦东新区新金桥路1888号36号楼7楼702室

电 话：+86-21-5046-3511 / 139-1883-7267

传 真：+86-21-5046-1490

官 网：<http://www.hakuto-vacuum.cn>





伯东企业（上海）有限公司
HAKUTO ENTERPRISES (SHANGHAI) LTD.
TEL: (86) 21-5046 3511 分机101 www.hakuto-vacuum.cn

伯东公司海外营业据点



上海伯东办公地址



上海总公司：
上海市长宁区凯旋路399号龙之梦雅仕大厦303室

金桥分公司(真空产品事业部)：
上海浦东新区新金桥路1888号36号楼7楼702室





伯东企业（上海）有限公司
HAKUTO ENTERPRISES (SHANGHAI) LTD.
TEL: (86) 21-5046 3511 分机101 www.hakuto-vacuum.cn

国际知名品牌授权代理商

上海伯东代理品牌包含：德国 Pfeiffer 全系列真空产品，美国 KRI 离子源总代理，美国 HVA 真空阀门总代理，美国 inTEST 高低温测试机总代理，美国 Gel-Pak 芯片包装盒代理，日本离子蚀刻机总代理，同时提供真空镀膜系统，氦检漏系统及配套真空零配件等。

上海伯东作为国际知名真空品牌指定代理商，全权负责在中国地区的销售和维修服务，100% 使用原厂进口零部件以及国外受训维修工程师：拥有完全的拆解，维修，校正能力并提供24小时在线服务。

					
					



srg technology



VIM-2

**True mobile
Spinning Rotor Gauge with Li Ion Technology**

Product Overview



VIM-2

First mobile Spinning Rotor Gauge with Li Ion Technology



Key Advantages

- True mobile Spinning Rotor Gauge (>2 h battery runtime)
- 10 mbar to 5×10^{-7} mbar measuring range
- Safe, all metal, ambient temperature
- Cost-effective two-part design
- Plug and measure, incl. App & Bluetooth
- Internal and external data logger
- High intrinsic accuracy and neglectable drift over time

Applications

- All thermal vacuum insulation applications
- All conductive vacuum insulation applications
- Documentation, QC, R&D, Preventive Maintenance
- Trouble shooting and safety check without opening the vacuum chamber



RS 485



24 VDC

The VIM-2 is a portable, battery-operated, highly accurate and long-term stable vacuum pressure gauge based on Spinning Rotor Gauge (SRG) technology.

Spinning Rotor Gauges are characterized, among other things, by the option to separate the sensor and measuring head / electronics and thus enable checking static vacuums in a very cost-effective manner. Due to its simplicity, the all-metal sensor can be permanently welded to the vacuum system and delivers reliable measured values even after years of use. Only the ball in the tube, and no electronic components, remain on the chamber to be measured. The system is uniquely resistant to mechanical stress and non-chlorinated corrosive media. Any interaction with the vacuum chamber takes place via electromagnetic forces that lift and accelerate the ball and measure its braking behavior. Corresponding mechanical protection that needs to be attached from the outside is included.

Advantages – Portability, accuracy and long-term stability

Spinning Rotor Gauges were previously considered to be complex to operate and were therefore almost exclusively used in calibration laboratories. A main application was, for example, the calibration of high vacuum measuring devices, ionization gauges.

The VIM-2, as a battery-operated device, is user-friendly, works largely independently and can be run remotely (App via Bluetooth). It is for instance particularly suitable for measurements on cryogenic, vacuum-insulated liquid gas tanks. It's a safe option as it does not require any electrical feedthroughs, making it an all-metal sensor that is extremely robust and resistant to aging. Compared e.g., to the Pirani-based measuring method, the measuring range is extended by approx. 3 decades into the high vacuum region, and thus provides greater and far more valuable information. It is a direct, mathematical / physical method, that only uses the effect of decelerating a rotating ball as it collides with the gas molecules as a measure of pressure.

Most other methods use ionization by means of hot filaments or high voltage to indirectly measure the pressure, they are

mechanically less stable and sensitive to contamination, even impact the vacuum pressure measurement themselves (by degassing/ionization and sputtering). Heat transfer methods (Pirani) have a limited measurement range below 10^{-3} mbar (w/o zeroing, which is often impossible). In general, all other UHV measurement methods have electrical feedthroughs and fragile electronic components in the vacuum part.

SRGs on the other hand have a unique high level of accuracy, long-term stability, no feedthroughs, measure with a simple sphere at ambient temperature, in a simple tube, all interaction with the vacuum is through electromagnetic forces.

The power supply-independent VIM-2 gives total mobility for large and remote measurement locations, it runs for hours before recharge.

Despite of SRGs of the past, a reliable measurement is provided due to the strong magnetic fields and high rotation frequency of the sensor. VIM-2 generates a magnetic field that is twice as strong (90 mT) as previously available SRGs. The standard rotation frequency of the sphere at 615 Hz provides a much more stable suspension in the magnetic field. Both effects result in an improved tolerance to imperfect alignment of the sensor tube on e.g., the cryo vacuum tank and more reliably capturing the sensor ball.

The measuring heads are not sensor-specific and therefore interchangeable with one another, and previously installed sensors, so each head can measure a large number of sensors without a significant loss of accuracy.

Measurement principle

The Spinning Rotor Gauge is based on the effect that gas molecules slow down a moving body as they are adsorbed on its surface and then re-emitted. The statistically distributed molecules striking from all directions are accelerated accordingly and break the body (momentum transfer, area-related particle flux density).

In the low-pressure regime ($< 1 \times 10^{-7}$ mbar) the desorption of the accelerated gas molecules does not contribute to the rotation frequency. At pressures above 1×10^{-4} mbar and mean free paths in the cm range, the gas viscosity is automatically compensated by means of an integrated temperature measurement.

In the case of the SRG, a simple precision ball is used as the sensor and the deceleration is determined by inductive measurement in the sensor head. Factors such as the molecular mass and temperature changes are only included in the measurement in an easily determinable root ratio.

Additionally, within small limits, variable factors determine the braking of the rotating ball:

1. The "residual drag" results from the material properties of the ball. It is particularly relevant for $< 10^{-5}$ mbar and can be roughly pre-determined and stored as required.
2. The "molecular drag" is the actual deceleration by the surrounding medium and proportional to the pressure. The molecular drag contains the calibration factor, which deviates from a ideally smooth sphere (factor 1) by max. $\pm 6\%$ without any calibration, $\pm 1\%$ can be achieved.

It should be noted that even without setting the calibration factor or the zero point, and even after years, the system still has a unique intrinsic accuracy in high vacuum, which cannot be achieved by any other vacuum measurement method and is more than sufficient for many applications.

Measurement range

Due to their principle, Spinning Rotor Gauges can be used in pressure ranges from atmosphere to UHV. Due to geometric and electromechanical conditions, however, they are optimized for the pressure range, in which they achieve uniquely high levels of accuracy and long-term stability:

1% accuracy of the measured value between 0.1 and 1×10^{-6} mbar can be achieved if needed, $< 1\%$ drift per year is typically. The measuring range in general is 10 mbar to 5×10^{-7} mbar, higher pressure values on request.

Technical Data

Measurement Principle	Spinning Rotor Gauge
Measurement Range	7 Torr to 4×10^{-7} Torr / 10 mbar to 5×10^{-7} mbar
Achievable accuracy	7 Torr to 0.07 Torr / 10 mbar to 0.1 mbar ca. 10 % of reading 0.07 to 7×10^{-7} Torr / 0.1 to 1×10^{-6} mbar 1 % of reading
Measurement time	3, 5, 10, 20, 30 s
Long term stability	< 1.5 % drift each year
Wetted materials	1.4404, 1.4034
Alignment	Horizontal
Analog interfaces	USB Type C, Bluetooth, High Density 15-polig
Digital interfaces	USB, Bluetooth, RS 232, RS 485
Internal data logger	1023 values
Remote control / GUI	Win7/10
Operating Temperature	Electronics 10 °C to 40 °C (50 F to 104 F) Measurement head 10 °C to 50 °C (50 F to 122 F) Sensor tube bakeable until 150 °C (302F) elastomer sealed 450 °C (842F) metal sealed
Power requirements	18 to 28 VDC
Analog output	0 bis 10 VDC configurable
Flange Type	KF 25, 8 VCR, welding socket
Weight	Device 1650 g (58 oz), power adapter 510 g (18 oz), head 750 g (26.5 oz)
Dimensions	L x B x H = 325 x 275 x 100 mm (13 x 11 x 4 in.)
Power consumption	Maximum 1.5 A at 24 VDC, typically < 1 A
Reaction time (fast mode)	1 s
Run time in battery mode	> 2 h
Battery charging time	In 4.5 h to more than 95% of current capacity

About us

ph-instruments develops, manufactures and sells vacuum measurement systems with unique technologies for demanding tasks in industry, research and science. Our guideline is to provide our customers with cost-effective and application-related solutions. Our specialists each have more than 20 years of experience in measuring and regulating pressures in the vacuum sector. The products are developed and produced in Germany and Austria and meet the highest quality standards for measuring accuracy, sustainability and reliability. Innovative technologies help to increase energy efficiency and thus protect the environment from unnecessary CO2 emissions.

Specifications can be changed without further notice.